


COLOUR TV SCHEMATIC DIAGRAM

MICRO ONECHIP

MICRO OM 8370

YOHNTOKIO



	INH	A, B, C
TV	1	1
AV1/SCARTS-VHS-YUV	0	0
AV2	0	1

PINS: LOW LEVER = S-VHS HIGH LEVER =AV1